

## Starting the Demo Unit

USB-cable must be connected (tester connector in the laptop) and the power must be on in the tester, in the relay matrix and in the laptop.

1. Use the user **Administrator**, username and the password will be sent separately
2. Start the **Safetest DB** (shortcut can be found in the middle of the screen)
  - Press **OK** in the first window (safetest version information)
  - Choose **TESTING** in the Safetest main window
  - Choose the program named **predisys**
  - Press **OK**
  - Please wait a moment → Program starts testing (The test plate starts to move)

If you want to show the analysis part, continue to the phase 3.

(Move the window lower if you like)

3. Choose **Finero Excel raportit** (again the shortcut/folder is in the middle of the screen)
  - Choose **Pikakuvake Meas\_Dashboard.xls**
  - Enlarge the view if you want

## Stopping the Demo Unit

Close first the analysis part, if it was open → phase 1.

1. Close **Meas\_Dashboard.xls**, **DO NOT SAVE IT!**

Then close the Safetest program → phase 2.

2. Press **STOP TESTING** in the **Ask Serial Number** window (Safetest)
3. Press **EXIT** in the Safetest 2000 main window
4. Shut down the computer